



## **MGFL 100**

### **Ground fault locator**

#### *USER GUIDE*

EN - ENGLISH

The information presented in this manual is believed to be adequate for the intended use of the product. If the product or its individual instruments are used for purposes other than those specified herein, confirmation of their validity and suitability must be obtained from Megger. Refer to the warranty information below. Specifications are subject to change without notice.

## **WARRANTY**

Products supplied by Megger are warranted against defects in material and workmanship for a period of two years following shipment. The warranty is void in the event of abuse (failure to follow recommended operating procedures) or failure by the customer to perform specific maintenance as indicated in this manual.

Megger

400 Opportunity Way

Phoenixville, PA, 19460

610-676-8500 (Telephone)

610-676-8610 (Fax)

[www.megger.com](http://www.megger.com)

**Contents**

<b>Section</b>	<b>Description</b>	<b>Page</b>
1.0	Introduction .....	4
1.1	Purpose of Manual .....	4
1.2	Audience.....	4
1.3	Items received .....	5
2.0	Safety .....	6
3.0	Technical specifications .....	7
4.0	Connections and Controls .....	9
4.1	Transmitter connections .....	9
4.2	Transmitter controls and displays .....	9
4.3	Receiver connections.....	10
4.4	Receiver controls and displays.....	10
5.0	MGFL100 Operations .....	10
5.1	Locating a fault on ungrounded DC systems.....	11
5.2	Locating a ground fault on IT grounded systems.....	20
5.3	Locating a ground fault on TT grounded systems .....	24
6.0	Setting voltage and current limits.....	25
7.0	Replacement parts.....	26
8.0	Maintenance .....	27
8.1	General .....	27
8.2	Receiver Battery Replacement .....	28
8.3	Transmitter Battery Replacement.....	28
8.4	Replacing source lead fuses .....	28
9.0	Sales and Manufacturing Sites.....	31

# 1.0 Introduction

## Section 1.0 Introduction

Thank you for your purchase of the Megger MGFL100 Ground Fault Locator. Be assured that your unit has been designed with emphasis on reliability, simplicity and ease of use. It will provide you with the information you need to locate various types of ground faults.

## Section 1.1 PURPOSE OF THIS MANUAL

This document is the operator manual for the Megger MGFL100 Ground Fault Locator. It provides a description of the operation of the unit as well as installation and operating instructions. Read this manual before installing or using the equipment. Special emphasis should be placed on all safety discussions.

## Section 1.2 AUDIENCE

This manual is written for technical personnel who are familiar with the various measurements performed by volt meters and current meters and have a general understanding of their use and operation. Such personnel should also be thoroughly familiar with the hazards associated with the use of this equipment and should have received proper safety training.

If you find any discrepancies in the MGFL100 or have any comments, please send them to Megger via fax, e-mail or phone.

Megger  
400 Opportunity Way  
Phoenixville, PA, 19460  
Attn: Customer Service

Fax: (214) 331 7397  
E-mail: [USTechSupportGrp@megger.com](mailto:USTechSupportGrp@megger.com)

For Technical Support please consult the Megger Web Site at [www.megger.com](http://www.megger.com) for the local distributor near you.

## Section 1.3 Items Received

Qty	Description	Image
1	MGFL100 Transmitter	
1	MGFL100 Receiver	

## 1.3 Items received

1	<b>Transmitter Output Cable</b>  Optional 6m (20ft) transmitter output cable available.	
1	<b>Current Clamp (CT)</b>	
1	<b>Sync Cable</b>	
Optional	<b>Capacitive Pick Up</b>	
Optional	<b>Active mini CT</b>	
Optional	<b>IT Filter</b>	
Optional	<b>Wide CT</b>	
Optional	<b>9m (30') Sync Cable</b> <b>NOTE: 9m (30ft) sync cable not EMC compliant</b>	

## 1.5 Definitions

### Section 1.4 Overview

The MGFL100 is a ground fault locator that is intended to be used to locate ground faults up to 400K ohms on online ungrounded DC systems. With use of the optional IT Filter the MGFL100 can also be used to locate ground faults up to 400K ohms on online IT grounded AC systems. The MGFL100 receiver can also be placed in a mode that will allow it to trace 60Hz and 50Hz currents on TT grounded systems with ground faults.

### Section 1.5 Definitions

This section defines the terms used throughout this manual.

Term	Definition
Impedance	The combined resistive and capacitive components of the ground fault on the circuit being measured, when the sync cable or Capacitive Pick Up is not used. When the sync cable or Capacitive Pick Up are used the term will refer to only the resistive component of the ground fault on the circuit being measured.
Capacitance	The leakage capacitance present in the circuit being measured.
Fault Current	The current delivered by the transmitter, used for tracing the fault.
Reactive Current	The portion of the fault current drawn by the capacitive portion of the circuit.
Transmitter	The part of the MGFL100 that provides the fault current and the direct measurement of the resistance and capacitance of the circuit.
Receiver	The part of the MGFL100 that measures the fault current and reactive current of the circuit.
Capacitive Pick Up	The accessory that when connected between the receiver and the circuit being measured allows the receiver to distinguish between the resistive and capacitive components of the fault current.
Sync Cable	The cable that is connected between the transmitter and receiver that allows the receiver to measure the reactive current of the circuit, without the need for the Capacitive Pick Up
CT	The current transformer or current clamp that connects to the receiver.
Active Mini CT	A battery powered miniature current clamp used to measure the fault current. This miniature current clamp fits in tight locations and on small wires.
IT Filter Box	The filter box that is placed between the transmitter and the IT grounded AC system. The box blocks the AC current from damaging the transmitter.

## Section 2.0 Safety

### Warnings and Safety Precautions



#### **WARNING!**

Death, serious injury, or fire hazard could result from improper use/installation of this instrument. Read and understand this manual before installing this instrument.

Installation of this instrument **MUST** be performed in compliance with the National Electric Code and any additional safety requirements applicable to your installation.

Installation, operation and maintenance of this instrument **MUST** be performed by qualified personnel only. The National Electrical Code defines a qualified person as one familiar with the construction and operation of the equipment and the hazards involved.

### Safety Precautions

The following safety precautions **MUST** be taken whenever the instrument is installed.

- Wear safety glasses and insulated gloves when making connections to power circuits
- Hands, shoes, floor/ground must be dry when making any connection to a powered line

These warnings and safety precautions are to be used where appropriate when following instructions in this manual.



#### CAUTION!

The equipment could be impaired from improper use. Read the complete manual before use.



#### CAUTION!

The system to be monitored might be influenced by the Insulation Fault Location System. IFLS.



#### CAUTION!

It is recommended to deactivate Insulation Monitoring Device (IMD) during ground fault tracing.



#### WARNING!

The equipment should not be used while its battery door is removed or if there is any visible damage to the case or if the hardware holding the unit together has been loosened.

### Section 3.0 Technical Specifications

SPECIFICATIONS REFERENCE	25°C (77°F)
<b>TRANSMITTER</b>	
Working Voltage	600 VDC max using fused test leads.
AC Power Adapter	100 to 264Vac 47-63Hz.
Output Voltage Range	0.0 to 50.0 V RMS
Output Frequency	5.12 Hz
Output Current	0 to 160 mA RMS
Output Power	5 Watts
Display	LCD, TN, Positive, Reflective Size: 0.4" high digits Format: Seven segment with decimal points Digits: 3.5
DC Voltage Measurement Range	0.0 VDC to 600 VDC
Accuracy	0 to 199.0V the accuracy = $\pm 5\%$ of display $\pm 0.2V$ 199.1V to 600V the accuracy = $\pm 5\%$ of display $\pm 2V$
Speed of Measurement	< 3 seconds
Display Resolution	0.0 VDC to 199.9 VDC / 200 VDC to 600 VDC Auto-ranging
Resistance Measurement Range	0.0 k $\Omega$ to 400 k $\Omega$
Resolution	0.1 k $\Omega$ ( $\leq 199.9$ k $\Omega$ ), 1 k $\Omega$ ( $> 199.9$ k $\Omega$ )
Accuracy	( $\pm 10 \pm 280 \times RC$ ) % $\pm 1$ Least Significant Digit
Speed of Measurement	< 3 seconds
Display Resolution	0.0 k $\Omega$ to 199.9 k $\Omega$ / 199.9 k $\Omega$ to 400 k $\Omega$ Auto-ranging
Capacitance Measurement Range	0.00 $\mu$ fd to 19.99 $\mu$ fd
Resolution	0.01 $\mu$ fd
Accuracy	$\pm 20\% \pm (.0027 / R)$ fd $\pm 1$ Least Significant Digit
Speed of Measurement	< 3 seconds
AC Voltage Measurement Range	0.0 V RMS to 50.0 V RMS
Resolution	0.1 V RMS
Accuracy	$\pm 5\%$ of reading $\pm 2$ Least Significant Digit
Speed of Measurement	< 3 seconds

## 3.0 Technical specifications

AC Current Measurement Range	0.0 mA RMS to 160 mA RMS
Resolution	0.1 mA RMS
Accuracy	±5% of display ± 0.2mA
Response time	< 3 seconds
Voltage limit	Password protected programmable from 0 to 50V
Current limit	Password protected programmable from 0 to 160mA
Battery Type	Four Li-Ion Protected Cells (18650)
Run Through Time	Up to 4 hours
Charge Time	Approx. 9.5 hours
Battery Status Indication	LED, Red / Amber / Green
<b>RECEIVER</b>	
Visual Alarm Range	Selectable - 30% / 40% / 50% / 60% / 70% of reference.
Audio Alarm Range	Selectable - 30% / 40% / 50% / 60% / 70% of reference.
Receiver Filter Range	Selectable 5.12Hz or 50 / 60Hz
Save	Saves Total Current, Resistive Current and Reactive Current
Recall	Recalls Total Current, Resistive Current and Reactive Current
Display	LCD, TN, Positive, Reflective Size: 0.4" high digits, Format: Seven segment with decimal points, Digits: 3.5
Resistive Current Measurement Range	0.00 mA to 160 mA
Resolution	0.01 mA (< 19.99 mA), 0.1 mA (> 19.99 mA)
Accuracy	±5% of reading ± 0.01 x IC ± 2 Least Significant Digits
Speed of Measurement	< 3 seconds
Capacitive Current Measurement Range	0.00 mA to 160 mA
Resolution	0.01 mA (<= 19.99 mA), 0.1 mA (> 19.99 mA)
Receiver IR Accuracy	±5% of reading ± 0.1 x IC ± 2 Least Significant Digits
Receiver IC Accuracy	±5% of reading ± 0.1 x IR ± 2 Least Significant Digits
Speed of Measurement	< 3 seconds
Battery Type	Six AA alkaline cells. (Eveready EN91, or equivalent).
Run Through Time	Up to 4 hours
Battery Status Indication	Visual: LED, Red / Amber / Green
<b>PHYSICAL</b>	
Transmitter Size	36.1 x 30.5 x 19.5 cm (14.2" x 12.0" x 7.65")
Transmitter Weight	6.00 kg (13.2 lbs). (with batteries installed)
Receiver Size	22.1 x 10.4 x 5.1 cm (8.7" x 4.1" x 2.0")
Receiver Weight	1.00 kg (2.2 lbs) (with batteries installed)
<b>ENVIRONMENTAL</b>	
Operating Temperature	-10°C to +50°C.
Storage Temperature	-20°C to 60°C
Humidity	95% Relative Humidity, Non-Condensing
IP Rating	51 when closed
<b>ALTITUDE</b>	
<2000 meters	600V CAT IV
2000-4000 meters	600V CAT III / 300V CAT IV
<b>SAFETY</b>	
Safety Standard	IEC61010
CAT Rating	IV @ 600V
<b>STANDARDS COMPLIANCE</b>	
Conducted EMI Immunity	IEC 61000-4-6 at 3V (150kHz to 80 MHz) Performance Criterion A
Radiated EMI Immunity	IEC 61000-4-3 at 10V/m (80 MHz to 1 GHz), 3V/m (1.4 GHz to 2.0 GHz) and 1 V/m (2.0 GHz to 2.7 GHz) Performance Criterion A
ESD Immunity	IEC 61000-4-2 with 4 kV contact discharges and 8 kV air discharges. Performance Criterion B
Conducted EMI Emissions When operating using external power adapter	CISPR 11 Group 1 class A for emissions IEC 61326-1 Table A.1 for immunity
Radiated EMI Emissions	CISPR 11 Group 1 class A for emissions IEC 61326-1 Table A.1 for immunity
Shock	MIL-STD-810G method 516.6
Drop test	MIL-STD-810G method 516.6


# 4.0 Connections and controls

Static Rigidity	IEC 61010-1 section 8.2.1
Impact	IEC 61010-1 section 8.2.2
Vibration	MIL-STD-810G method 514.6 Annex C
Loose Cargo	MIL-STD-810G method 514.6 category 5.


\* Full Accuracy Specification guaranteed 0°C to 50°C

## Section 4.0 Connections and Controls

### Section 4.1 Transmitter Connections



### Section 4.2 Transmitter Controls and Displays



## 4.3 Receiver connections

### Section 4.3 Receiver Connections



The current clamp plugs into the CT inputs.  
The sync cable will plug into the "SYNCH" input.

### Section 4.4 Receiver Controls and Displays

<p>Battery test button: Press to view the status of the receiver batteries. (Red should be replaced)</p>	<p>The image shows the front of the Megger MGL100 receiver. It has a digital display at the top with 'I<sub>R</sub>' and 'I<sub>C</sub>' indicators. Below the display are several buttons: a battery test button (red), a power button (green), a function button (blue 'Fn'), and a recall button (blue). A large rotary knob is in the center, and a save button (blue) is at the bottom. There are also two small LEDs on the right side of the display area.</p>	<p>IT indicator: When lit this indicates the displayed value is total current.</p>
<p>Power On / Off: Press button to power the unit on and off.</p>		<p>Alarm indicator: Lights when the receiver locates the circuit with the fault.</p>
<p>Function button: Press button to deactivate the low pass filter in order to trace 50/60Hz current.</p>		<p>Save LED: Lights during save operation.</p>
<p>Alarm knob: Selects alarm level and audio / visual alarm.</p>		<p>Recall button: Press to recall saved values.</p>

## Section 5.0 MGFL100 Operation

### Section 5.1 Locating ground faults on ungrounded DC systems

#### Before operating

Verify the battery in the transmitter is fully charged, if the unit is to be operated off of battery.

Turn on the transmitter and verify the battery indicator displays a fully charged battery



Verify the receiver batteries are good.



Fresh battery in the active mini CT if using



#### Connection

Connect the green safety earth cable from the safety ground on the unit to earth.

This can be a pipe or conduit that is tied to earth or an earth stake or equivalent.



Connect the green terminal to earth.

This can be a pipe or conduit that is tied to earth or an earth stake or equivalent.



## 5.1 Locating ground faults on ungrounded DC systems

Connect the black terminal to the negative side of the battery string.



Connect the red terminal to the positive side of the battery string.



### CAUTION

Do not connect the equipment across voltages that exceed 600Vdc. This could cause damage to the unit.



### WARNING!

Use only the provided fused test leads for connection to the battery.



### WARNING!

Wear proper PPE equipment when connecting the unit. Do not place the transmitter on unstable surfaces or on the batteries or battery rack.

If operating the transmitter off of AC then plug the power adapter into transmitter as shown.

Then plug the power adapter into an AC outlet.

The power outlet must be from 90 to 264Vac 47 – 63Hz.

If powering off of battery the AC adapter is not required. A fully charged battery should last approximately 4 hours.



After the MGFL100 is connected follow the procedure below.

**Step 1:** Turn ON the MGFL100 transmitter and allow it to boot up.

During boot up the following sequence will take place.

## 5.1 Locating ground faults on ungrounded DC systems

All LED's will display "1888" for 3 seconds.

The firmware version will be displayed on the lower left Voltage Display and the build on the right.

After the boot up is complete:

View the positive and negative voltages as displayed in the top displays.

The display with the lower voltage indicates the side of the string with the ground fault.



**Step 2:** Press the appropriate output button based on the side of the string that has the fault.

If the positive voltage reads lower than the negative voltage then press the "+" button.

If the negative voltage reads lower than the positive voltage then press the "-" button.

A count down will ensue while the isolation caps charge up.

Once the countdown is complete.


Turn the voltage adjustment knob clockwise until the voltage reads approximately 10V.

**NOTE:** If the IT filter and Transmitter are connected to a line that does not contain a ground fault then the transmitter may not transition from the voltage monitoring mode to the excitation mode. The countdown timer may stay at "10". This is due to the residual AC voltage appearing across the charging current limiter and never being balanced by the coupling capacitor.

Note the readings on the top displays.

The left display will indicate the resistive value of the fault.

The right display will indicate the capacitance on the circuit.



## 5.1 Locating ground faults on ungrounded DC systems

### Problem: No readings are displayed.

If OL is displayed for the resistive reading then this can indicate a high impedance fault. Continue raising the voltage until a stable reading is shown.

There is no problem if the capacitive reading displayed is 0.00. This just means there is minimal stray capacitance on the circuit.

### Step 3: Connect the receiver:

Connect the current clamp to the receiver and place the current clamp around either the positive or negative output lead. Whichever one is outputting the current to the fault.



Connect the sync cable between the receiver and transmitter



Note the readings on the displays.

The top display will indicate the current the fault is drawing.

The lower display will indicate the reactive current drawn by stray capacitance on the circuit.

It is the actual fault current on the top display that will be traced.



### Step 4: Press the SAVE button on the receiver.

This will save 3 values.

The total current being drawn by the circuit.

The resistive current being drawn by the fault. (The fault current)

The reactive current being drawn by stray capacitance.

## 5.1 Locating ground faults on ungrounded DC systems

These values can be recalled by pressing the recall button on the receiver.



Set the alarm level on the receiver to 50%. This can be either a visual only alarm or a visual and audio alarm, depending on how it is set



If there are multiple panels then perform the procedure below. If there is only one panel skip to step 6.

**Step 5:** Place the CT around the wires that lead to each panel. **(Do not disconnect the sync cable)**

If the alarm is set to 50% then it will trigger if it sees a fault current in excess of 50% of the saved value.

Locate the panel drawing the fault current.

**Problem: The measured value on the receiver will not stabilize.**

This may indicate a level of low frequency noise on the circuit. Place the CT around both the positive and return wires of each circuit. This will cancel out any noise on the system.

## 5.1 Locating ground faults on ungrounded DC systems

### **Problem: More than 1 panel indicates fault current.**

This may indicate that there are multiple faults. View the fault current on the top display of the receiver for each panel. Identify the panel drawing the highest level of fault current. This is the panel where to start the tracing process.

### **Problem: No panels indicate fault current.**

There may be multiple faults on various circuits. Lower the alarm level on the receiver from 50% to a lower value then repeat the measurements. If no fault can be identified then the fault is before the panels. Begin tracing from the batteries to the panels.

**Step 6:** Once the panel is identified, remove the cover of the panel in order to expose the circuit wires.

Place the CT around the each wires of each circuit in the panel. **(Do not disconnect the sync cable)**

### **Problem: More than 1 circuit indicates fault current.**

This may indicate that there are multiple faults. View the fault current on the top display of the receiver for each panel. Identify the circuit drawing the highest level of fault current. This is the circuit where to start the tracing process.

### **Problem: No circuits indicate fault current.**

There may be multiple faults on various circuits. Lower the alarm level on the receiver from 50% to a lower value then repeat the measurements. If no fault can be identified then the fault is before the panel. Begin tracing from the batteries to the panel.

Once the circuit is identified the tracing of the fault can begin.

**Step 7:** Tracing the ground fault.

Be sure to have a schematic of the circuit being traced.

If using Capacitive Pick Up go to section on using the capacitive pick up.

### **Not using Capacitive Pick Up.**

Disconnect the sync cable from the receiver.

The receiver will now only display the total current drawn by the circuit on the top display. This will be inclusive of both the fault current and any current drawn by stray capacitance.

The alarm will now be triggered when the measured current exceeds the selected percentage of total current.

Push the recall button and note the value of the total current.

## 5.1 Locating ground faults on ungrounded DC systems




Using the schematic of the circuit, start tracing the fault current through the circuit.

Move the current clamp down the circuit to trace the fault.

If the fault current is displayed on the top display of the receiver then the fault is still downstream.

If the fault current is no longer displayed on the top screen of the receiver then you have passed the fault. Use this technique to narrow down the location of the fault until it is located.



### **Problem: The fault current splits along 2 different paths.**

This may be due to 2 separate faults or it may be due to stray capacitance on the circuit. If you have a Capacitive Pick Up connect it to the receiver using the sync cable. Then place both the current clamp and the Capacitive Pick Up on the same line. The receiver will now display the fault current on the top display and leakage current on the bottom display. Continue tracing on the circuit that is drawing the most fault current, as shown on the top display.

If you do not have a Capacitive Pick Up then you can do the same procedure above by moving the transmitter and connecting the sync cable between the transmitter and the receiver.

## 5.1 Locating ground faults on ungrounded DC systems



### **Problem: The Current Clamp is too large to get around the cable.**

Use the active mini CT to measure the fault current on the small insulated cables. Be sure the CT has a good battery. Since the active CT has a different size core the fault current measurement may not exactly match the larger CT. It is recommended to re-establish a reference value by placing the active mini CT on the last point measured and then pressing the SAVE button on the receiver. Note the saved value.



### **CAUTION!**

Once fault is found turn off transmitter before clearing fault. Failure to do so, could trip a breaker.

### **Using Capacitive Pick Up.**

Disconnect the sync cable from the transmitter and connect it to the Capacitive Pick Up.

Connect the Capacitive Pick Up ground cable to earth.

Then place both the current clamp and the Capacitive Pick Up on the same line. This needs to be an insulated wire. The receiver will now display the fault current on the top display and leakage current on the bottom display. If the value of the fault current on the top display exceeds the value of the leakage current on the bottom display then a real fault exists on the cable. If the leakage current on the bottom display exceeds the fault current on the top display then the cable has stray capacitance.

The alarm will trigger when the fault current exceeds the percentage set on the receiver.

Only trace the paths with the real fault current.

Push the recall button and note the total values of the fault current and reactive current.

## 5.1 Locating ground faults on ungrounded DC systems



Using the schematic of the circuit, start tracing the fault current through the circuit.

Move the current clamp down the circuit to trace the fault.

If the fault current is displayed on the top display of the receiver then the fault is still downstream.

If the fault current is no longer displayed on the top screen of the receiver then you have passed the fault. Use this technique to narrow down the location of the fault until it is located.

### **Problem: The Current Clamp is too large to get around the cable.**

Use the active mini CT to measure the fault current on the small insulated cables. Be sure the CT has a good battery. Since the active CT has a different size core the fault current measurement may not exactly match the larger CT. It is recommended to re-establish a reference value by placing the active mini CT on the last point measured and then pressing the SAVE button on the receiver. Note the saved value.



### **CAUTION!**


Once fault is found turn off transmitter before clearing fault. Failure to do so, could trip a breaker.

## 5.2 Locating ground faults on IT grounded systems

### Section 5.2 Locating ground faults on IT grounded systems

#### Connection

Connect the green safety earth cable from the safety ground on the unit to earth.  
This can be a pipe or conduit that is tied to earth or an earth stake or equivalent.



Connect the green terminal to the IT Filter box input.



Connect the red terminal to the IT Filter box input.



Connect the output of the IT Filter between earth and the IT circuit with the ground fault.



#### CAUTION!

Do not connect the equipment across voltages that exceed 600Vac. This could cause damage to the unit.

## 5.2 Locating ground faults on IT grounded systems



### WARNING!

Use only the provided fused test leads for connection to the battery.



### WARNING!

Wear proper PPE equipment when connecting the unit. Do not place the transmitter on unstable surfaces or on the batteries or battery rack.

If operating the transmitter off of AC then plug the power adapter into transmitter as shown.

Then plug the power adapter into an AC outlet.

The power outlet must be from 90 to 264Vac 47 – 63Hz.

If powering off of battery the AC adapter is not required. A fully charged battery should last approximately 4 hours.



After the MGFL100 is connected follow the procedure below.

**Step 1:** Turn ON the MGFL100 transmitter and allow it to boot up.

During boot up the following sequence will take place.

All LED's will display "1888" for 3 seconds.

The firmware version will be displayed on the lower left Voltage Display and the build on the right.

**Step 2:** After the boot up is complete press the positive voltage "+" button.

A count down will ensue while the isolation caps charge up.

Once the countdown is complete.

Turn the voltage adjustment knob clockwise until the voltage reads approximately 10V.

**NOTE:** If a low impedance fault to earth is present you may see the current rising while the voltage does not. In this case adjust the voltage knob until the current display indicates approximately 10 to 25mA.

Note due to the inclusion of the AC rejection filter, the displayed resistance and capacitance readings are not the resistance and capacitance to ground of the IT system. Only measurements made with the Receiver on cables after the AC Rejection Filter using the Capacitive Pickup connected to the drive line after the AC Rejection Filter will be accurate.

### **Problem: No readings are displayed.**

If OL is displayed for the resistive reading then this can indicate a high impedance fault. Continue raising the voltage until a stable reading is shown.

There is no problem if the capacitive reading displayed is 0.00. This just means there is minimal stray capacitance on the circuit.

## 5.2 Locating ground faults on IT grounded systems

### Step 3: Connect the receiver:

Connect the current clamp to the receiver.



Connect the sync cable between the receiver and the Capacitive Pick Up.



Connect the Capacitive Pick Up ground to earth.



Place the current clamp on the positive lead of the transmitter after the IT Filter box.



Connect the Capacitive Pick Up to the positive lead of the transmitter after the AC Filter box.




**Note** the readings on the receiver displays.

The top display will indicate the current the fault is drawing.

The lower display will indicate the reactive current drawn by stray capacitance on the circuit.

It is the actual fault current on the top display that will be traced.

## 5.2 Locating ground faults on IT grounded systems



**Step 4:** Press the SAVE button on the receiver.

This will save 3 values.

The total current being drawn by the circuit.

The resistive current being drawn by the fault. (The fault current)

The reactive current being drawn by stray capacitance.

These values can be recalled by pressing the recall button on the receiver.



Set the alarm level on the receiver to 50%. This can be either a visual only alarm or a visual and audio alarm, depending on how it is set.



Be sure to have a schematic of the circuit being traced.


## 5.3 Locating ground faults on TT grounded systems

**Step 5:** Using the schematic of the circuit, start tracing the fault current through the circuit.

Move the current clamp down the circuit to trace the fault.

If the fault current is displayed on the top display of the receiver is approximately unchanged then the fault is still downstream.

If the fault current displayed on the top screen of the receiver is significantly lower then you have passed the fault. Use this technique to narrow down the location of the fault until it is located.



**Problem: The Current Clamp is too large to get around the cable.**

Use the active mini CT to measure the fault current on the small cables. Be sure the CT has a good battery. Since the active CT has a different size core the fault current measurement may not exactly match the larger CT. It is recommended to re-establish a reference value by placing the active mini CT on the last point measured and then pressing the SAVE button on the receiver. Note the saved value.

### Section 5.3 Locating ground faults on TT grounded systems

To locate ground faults on TT grounded systems only the MGFL100 receiver is required.

Before operating verify the receiver has a fresh battery and schematics of the system to be troubleshot.

Connect the CT to the receiver.

Place the receiver in 50/60Hz mode by pressing the filter button.

In this mode the top LCD will display a tilde mark “~” and the lower LCD will be blank.

## 6.0 Setting Voltage and Current Limits



The receiver will now measure the fundamental current.


Place the CT around the wires to see the path of the current.

Place the CT around the earth and note the fault current. Now reference the schematic and trace back to locate the fault.

### Section 6.0 Setting Voltage and Current Limits

To set maximum voltage and current limits verify the transmitter is powered off.

While holding down both the "+" and "-" buttons at the same time turn on the transmitter. Continue holding the down both the "+" and "-" buttons while the transmitter boots up.



Once the transmitter had completed booting the lower left voltage display will be flashing.



## 7.0 Replacement Parts

Turn the rotary knob clockwise until the password “527” is displayed.  
Then push the “+” button to enter the password.

Set the maximum voltage limit by turning the rotary knob until the desired limit is displayed.  
Then push the “+” button to enter the voltage limit.

Now set the maximum current limit by turning the rotary knob until the desired limit is displayed.  
Then push the “+” button to enter the current limit.

Once the desired limits are set turn off the transmitter.

Turn the transmitter back on. During the boot up sequence the maximum voltage and current limits will be displayed in the voltage display and current display.



### Section 7.0 Replacement Parts

Parts listed below are user replaceable consumable materials and accessories.

Item	Part Number	Description	Notes
<b>Transmitter batteries</b>	90028-218	Lithium Ion battery cells that power the transmitter.	Supplied by manufacturer only
<b>Standalone Battery Charger</b>	90037-318	Optional high speed standalone battery charger	Supplied by manufacturer only
<b>Receiver batteries</b>	23415	Standard AA battery	Alkaline or Lithium battery can be used.
<b>Active CT battery</b>	35940	Standard 9 Volt battery for active mini CT.	Alkaline or Lithium battery can be used.
<b>Output cable fuse</b>	90028-208	2A fast blow 1000V 32mm	
<b>Transmitter output cables</b>	1013-440	Set of output cables for transmitter including fuses.	Supplied by manufacturer only
<b>Transmitter sync cable</b>	1011-540	Cable that syncs the receiver to the transmitter and also used with capacitive pick up.	Supplied by manufacturer only
<b>Transmitter AC Power Adapter</b>	90028-308	AC Power Wall Adapter used for powering transmitter and charging batteries.	Supplied by manufacturer only

<b>Transmitter</b>	1011-308	Transmitter that outputs signal to locate fault. Complete with cables and AC power adapter.	Supplied by manufacturer only
<b>Receiver</b>	1011-309	Receiver that displays fault current and reactive current. Includes ICLAMP and sync cable.	Supplied by manufacturer only
<b>ICLAMP</b>	1011-353	Accessory – 2" ID current clamp.	Supplied by manufacturer only
<b>Active mini CT</b>	1013-424	Optional Accessory – Miniature CT for tight locations.	Supplied by manufacturer only
<b>Capacitive Pick Up Probe</b>	1011-354	Optional Accessory – Probe used for identifying false paths.	Supplied by manufacturer only
<b>IT Filter Box</b>	1014-289	Optional Accessory – Used for locating faults on IT grounded systems.	Supplied by manufacturer only
<b>Magnetic Strap</b>	1010-013	Optional Accessory – Connects to the receiver allowing it to be attached to ferrous metal surfaces.	Supplied by manufacturer only
<b>Clip Strap</b>	1011-374	Clip Strap – Allows the receiver to be hung from the lips of surfaces.  Can be hung on lips of surfaces up to 6mm (¼") wide.	Supplied by manufacturer only
<b>9m (30ft) Sync Cable</b>	1015-367	9 Meter (30ft) Sync Cable - Useful when the panel is not close to the battery string.	Supplied by manufacturer only
<b>6m (20ft) Transmitter Leads</b>	1014-091	6m (20ft) Transmitter Leads - Useful when the transmitter cannot be easily located near the battery string.	Supplied by manufacturer only

### Section 8.0 Maintenance

#### Section 8.1 General

1. The following general maintenance should be carried out on the MGFL100 in order to ensure proper operations.
2. Charge the transmitter batteries at least once every 4 months. This ensures the batteries do not overly self-discharge.
3. Clean the ICLAMP core mating surface using a clean cloth. This will remove any grease of contaminates and ensure a good mating surface.
4. The transmitter and receiver can be cleaned and disinfected by using alcohol.
5. Documentation will include instructions for cleaning and decontamination.

**NOTE:** Since this instrument is used for tracing faults and not for taking precise measurements, calibration is not technically required. Any desired calibration interval is at the user's discretion.

## 8.2 Receiver battery replacement

### Section 8.2 Receiver battery replacement



Verify the receiver is powered off.

Remove the single screw holding the rear battery panel on the receiver.

Remove the panel to access and replace the batteries.

Receiver batteries should be removed when the receiver is stored for long periods.

### Section 8.3 Transmitter Battery Replacement



Verify the transmitter is powered off.

Press in the front clip on the battery compartment and carefully remove the battery cover panel.

The batteries can now be replaced.

### Section 8.4 Replacing source lead fuses

Each source lead (Both the red and black) contain a safety fuse in the handle.



The fuse rating is 2A Fuse 1000V 32mm. Megger part number 90028-208

**NOTE:** The fuse cover should never be removed while the clamp is connected to the MGFL100 Transmitter or to a battery.

## 8.4 Replacing source lead fuses

## 8.4 Replacing source lead fuses

### Replacing the Source Lead Fuse

#### Step 1

Remove the clamp screw on the inside of the handle.



#### Step 2

Lift up the rear of the plastic guard



Then pull back to remove the guard and expose the fuse



#### Step 3

Use a small screw driver to gently pry out the fuse from the holder




#### Step 4


Replace the fuse



#### Step 5

Re-install the guard by sliding the guide slot under the guide screw





### Section 9.0 Sales and Manufacturing Sites

#### Local Sales Office

Megger USA - Valley Forge Valley Forge Corporate Center 400 Opportunity Way

Phoenixville, PA, 19460

T. 1-610 676 8500

F. 1-610-676-8610

#### Manufacturing Sites

<p>Megger Limited Archcliffe Road Dover Kent CT17 9EN ENGLAND T. +44 (0)1 304 502101 F. +44 (0)1 304 207342</p>	<p>Megger GmbH Obere Zeil 2 61440 Oberursel, GERMANY T. 06171-92987-0 F. 06171-92987-19</p>
<p>Megger USA- 400 Opportunity Way Phoenixville, PA, 19460 T. 1-610 676 8500 F. 1-610-676-8610</p>	<p>Megger USA Dallas 4271 Bronze Way Dallas TX 75237-1019 USA T 800 723 2861 (USA only) T. +1 214 333 3201 F. +1 214 331 7399 USsales@megger.com</p>
<p>Megger AB Rinkebyvägen 19, Box 724, SE-182 17 DANDERYD T. 08 510 195 00 E. seinfo@megger.com</p>	

## Manufacturing sites

---

Megger Limited  
Archcliffe Road  
Dover  
Kent  
CT17 9EN  
ENGLAND  
**T.** +44 (0)1 304 502101  
**F.** +44 (0)1 304 207342

Megger GmbH  
Weststraße 59  
52074  
Aachen  
Germany  
**T.** +49 (0) 241 91380 500  
**E.** [info@megger.de](mailto:info@megger.de)

Megger  
400 Opportunity Way  
Phoenixville, PA, 19460  
**T.** 1-610 676 8500  
**F.** 1-610-676-8610

Megger USA - Dallas  
4545 West Davis Street  
Dallas  
75211-3422  
**T.** +1 214 333 3201  
**F.** +1 214 331 7399  
[USSales@megger.com](mailto:USSales@megger.com)

Megger AB  
Rinkebyvägen 19, Box 724,  
SE-182 17  
DANDERYD  
**T.** 08 510 195 00  
**E.** [seinfo@megger.com](mailto:seinfo@megger.com)

Megger Baker  
4812 McMurry Avenue  
80525  
USA  
**T.** +1 970-282-1200  
**E.** [baker.sales@megger.com](mailto:baker.sales@megger.com)

The company reserves the right to change the specification or design without prior notice.

Megger is a registered trademark

The Bluetooth<sup>®</sup> word mark and logos are registered trademarks owned by Bluetooth SIG, Inc and is used under licence.

Part No: MGFL100\_UG\_en\_V02